


PRODUCT SPARE PARTS INFO:

MANF: RCF spa




Unit 17 Lynderswood Farm
 London Road, Black Notley
 Braintree, Essex CM77 8QN
 Tel: 01245 361578
 Fax: 01245 361357

email: sales@audio-workshop.co.uk

MODEL: ART200A

DESCRIPTION: Active Bi-amped Loudspeaker & Mixer
 12 inch bass 1 inch HF compression driver
 LF 120 watts HF 40 watts
 XLR in/out


PART NO: DESCRIPTION



15410085 HF DIAPHRAGM

To fit replacement diaphragm, DISCONNECT POWER LEAD. Remove rear panel , disconnect cables from speaker and HF driver, making note of what colour goes to each terminal. Remove 3 allen screws holding HF driver rear cover in place, remove old and fit new diaphragm. Note the + terminal is aligned with the + mark on the rear cover plate.

11401022 COMPLETE BASS DRIVER
 or
 11444001 RE CONE KIT ONLY
 (not supplied with glue)




33093410 CABINET FRONT

33090390 CABINET REAR

13401009 PROTECTION GRILL

33890100 RUBBER FOOT



23102060 SUPPORT FOOT (SIDE USE)
 Not Shown

23101820 AMPLIFIER ASSEMBLY

Remove all outer 12 rear panel screws to gain access to amplifier. We sometimes have refurbished exchange amplifier modules available, please telephone for further info.



**Please refer all repairs to a Qualified audio / electronics engineer.
 240v ac mains is lethal if not teated with respect.**